

EXCALIBUR & CRUSADER MAINTENANCE SCHEDULE



NOTE: Lack of maintenance may result in premature failure of components.

NOTE: Parts marked with * should be cleaned daily.

NOTE: Maintenance schedule may vary due to gas heating value per country.

NOTE: Specially requested “buyout components” (equipment manufactured by others) such as Hatco, Sodir, Vollrath, and Woodstone, will be supplied with a manual providing maintenance and service instructions specific to that piece of equipment.

NOTE: When flue plates are removed, confirm proper orientation during re-installation to ensure flue passages are not obstructed.

NOTE: Please refer to specific product manual for detailed maintenance instructions.



MAINTENANCE PROCEDURES
1. Inspect
2. Clean
3. Adjust
4. Replace (As Needed)
5. Lubricate

EXCALIBUR & CRUSADER MAINTENANCE SCHEDULE

Components listed cover all applicable models

Components marked with “!” require maintenance performed by an authorized service agent

	JAN	FEB	MAR	APR	MAY	JUNE	JULY	AUG	SEPT	OCT	NOV	DEC
Air Mixers (All Models)	2	2	2	2	2	2	2	2	2	2	2	2
Bearings (OFB)	1,5			1,5			1,5			1,5		
Blower Wheel (All Models)	1,2			1,2			1,2			1,2		
Bottom Grate (UFB)	1,2			1,2			1,2			1,2		
Burner Valves (All Models)	1,5			1,5			1,5			1,5		
Burners (All Models)	1,2,4			1,2,4			1,2,4			1,2,4		
Ceramics (OFB)	1,2,4			1,2,4			1,2,4			1,2,4		
Circuit Breaker (Vectaire) !												
Contactors (Vectaire) !												
Door Seals (Vectaire)	1,3			1,3			1,3			1,3		
Door Switch (All Models)	1,3			1,3			1,3			1,3		
Debris Screen (All Models)*	2	2	2	2	2	2	2	2	2	2	2	2
Drain Valve (Fryer)	2	2	2	2	2	2	2	2	2	2	2	2
Drip Tray (All Models) *	2	2	2	2	2	2	2	2	2	2	2	2
Door Bearings (All Models)	1,5			1,5			1,5			1,5		
Elements (Vectaire) !	1						1					
Electronic Ign. (Vectaire) !	1						1					
Fan Switch (All Models)	1,4						1,4					
Fry Basket (Fryer) *	2	2	2	2	2	2	2	2	2	2	2	2
Fry Top (All Models) *	2	2	2	2	2	2	2	2	2	2	2	2
Gasket (OFB)	1,4						1,4					
Grates (All Models) *	2,5	2,5	2,5	2,5	2,5	2,5	2,5	2,5	2,5	2,5	2,5	2,5
Grid (OFB, Charcoal) *	2	2	2	2	2	2	2	2	2	2	2	2

EXCALIBUR & CRUSADER MAINTENANCE SCHEDULE

Components listed cover all applicable models

Components marked with “!” require maintenance performed by an authorized service agent

	JAN	FEB	MAR	APR	MAY	JUNE	JULY	AUG	SEP	OCT	NOV	DEC
Grid Frame (OFB, UFB)	1,2						1,2					
Grease Cont. (All Models) *	2	2	2	2	2	2	2	2	2	2	2	2
Gear (OFB)	1,5			1,5			1,5			1,5		
Hi Limit (Vectaire) !												
Insulation, Motor (All)	1,4						1,4					
Motor (All Models)	1,2			1,2			1,2			1,2		
Oven Racks (All Models) *	2	2	2	2	2	2	2	2	2	2	2	2
Pilots (All Models)	1,2,4			1,2,4			1,2,4			1,2,4		
Pilot Safety (All Models) !												
Radiant (UFB)	1,2,4			1,2,4			1,2,4			1,2,4		
Radiant Reflector (UFB)	1,2,4			1,2,4			1,2,4			1,2,4		
Regulator (Vent)	1,2						1,2					
Searing Plate (SHB) *	2	2	2	2	2	2	2	2	2	2	2	2
Swing Faucet (CR)	1						1					
Timer (Vectaire)	1						1					
Thermostat (All Models) !	1,3						1,3					
T-Couple (All Models)	1,4						1,4					
Thermopile (Fryer)	1,4						1,4					
Turnbuckles (Vectaire)	1,3,5			1,3,5			1,3,5			1,3,5		
Valve, Pilot (All Models)	1,2			1,2			1,2			1,2		
Wok Bowl (CR) *	2	2	2	2	2	2	2	2	2	2	2	2
Water Valve (CR)	1						1					
Flue Plates (All Suites) !	1						1					